

















Switch Master












Position

Pad Number

Pad Number

Pad Number


- Freq
- 1 Off
 - 2 27Hz
 - 3 47Hz
 - 4 82Hz
 - 5 150Hz
 - 6 270Hz



To Position 6A Lower Filter Switch

Upper Filter Switch

Switch Type
3 Pole x 6 Position



Lower Filter Switch

Switch Type
3 Pole x 6 Position

